

Temperature gauge, pressure gauge, rudder angle gauge, trim gauge, fuel gauge, fresh water gauge for lever-type sensor	B000046	11/18	1

This manual is related to the following product

<p>A2C60001078 A2C60001028 A2C59514170 A2C59514111 A2C59514154 A2C60001032 A2C60000994 A2C60001076 A2C59514160 A2C59514123 A2C60001025 A2C60000935 A2C60001065 A2C60001062 A2C59514097 A2C59514136 A2C60001080 A2C60001035 A2C60000972 A2C60000958 A2C60001068 A2C59514141 A2C59514211 A2C60001066 A2C59514893 A2C59514230 A2C59514915 A2C59514237 A2C60000964 A2C59514149 A2C59514180 A2C59514199 A2C59514244 A2C59514206 A2C60000998 A2C60001038 A2C60001021 A2C59501018 A2C59501018 A2C60000957 A2C60000968 A2C60000961 A2C59514174 A2C59514099 A2C60000962 A2C59514231 A2C60000971 A2C60001022 A2C60001020 A2C60001049 A2C60001045 A2C60001047 A2C59514112 A2C59514113 A2C59514114 A2C59514124 A2C59514128 A2C59514137 A2C59514139 A2C59514152 A2C59514201 A2C59514202 A2C59514208 A2C59514213 A2C59514223 A2C59514228 A2C60000967 A2C60000969 A2C60000970 A2C60000985 A2C60000990 A2C60001023 A2C60001024 A2C60001026 A2C60001027 A2C60001034 A2C60001036 A2C60001037 A2C60001044 A2C60001147 A2C60000983 A2C60001030 A2C59514171 A2C59514172 A2C59514173 A2C59514238 A2C59514239 A2C60000950 A2C60000951 A2C60000952</p>	<p>MODULE TEMP WATER 250F/120C VDO 12/24 VL MODULE OIL 80PSI/5BAR 10-180 12/24 VLB VLW TempWa 12/24V 52 120C D EU DL rb A VLW PressOil 12/24V 52 10bar D EU DL rb VLW Rudder 12/24V 52 40 Stb S DL rb A MODULE GEAR 400PSI/30BAR 10-180 12/24VLB MODULE OIL 150PSI/10BAR 10-180 12/24 VLB VLW_WaTemp12/24V_52_120°C_D_EU_DL_wo_C VLW TempOil 12/24V 52 150C D EU DL rb A VLW PressOil 12/24V 52 5bar D EU DL rb A VLW_OilPress12/24V_52_10 bar_D_EU_DL_wo VLW Temp Wa 12V 52 EG dc C Manitou MODULE RUDDER -40/+40 52MM 12/24 VLB MODULE FRESHWATER E-F 10-180 12/24 VLB VLW LevelFw 12/24V 52 1/1 S LT EU DL rb VLW PressTr 12/24V 52 25bar D EU DL rb A VLW_WaTemp12/24V_52_120°C_D_EU_DL_wo_C VLW_OilPress12/24V_52_5 bar_D_EU_DL_wo_ MODULE OIL 80PSI 10-180 12/24 VLB MODULE TEMP WATER 250F VDO 12/24 VLB MODULE TRIM MERC/VOLVO/YAMAHA 12/24 VLW VLW PressTr 12/24V 52 30bar D EU DL rb A VLW PressOil 12/24V 52 5bar D EU DL rw A MODULE RUDDER -40/+40 52MM 12/24 VLW VLW Rudder 52 12+24 40° STB S DL rw C VLW Rudder 12/24V 52 40 Stb S DL rw A VLW RUDDER 12+24V 52 40° Stb S DL tc C VLW TempWa 12/24V 52 120C D EU DL rw A MODULE TEMP WATER 250F VDO 12/24 VLW VLW PressTu 12/24V 52 2bar D EU DL rb A VLW Trim 12/24V 52 Down S BRAVO DL rb A VLW PressOil 12/24V 52 10bar D EU DL rw VLW TRIM 12/24V 52 Down S Bravo DL rw A VLW PressOil 12/24V 52 25bar D EU DL rw MODULE AIR 150PSI/1KkPa 10-180 12/24 VLB VLW_OilPress12/24V_52_30 bar_D_EU_DL_wo MODULE TEMP WATER 250F/120C VDO 12/24 VL Panel, pressure, cluster 2, MAN Panel, pressure, cluster 2, MAN MODULE TEMP WATER 240F US 12/24 VLB VLW_OilPress12/24V_52_10 bar_S_EU_DL_wo VLW_WaTemp12/24V_52_120°C_S_EU_DL_wo_C VLW TempHy 12/24V 52 120C S EU DL tb A VLW LevelFw 12/24V 52 F S LT EU DL rb A VLW_OilTemp12/24V_52_150°C_S_EU_DL_wo_C VLW TempOil 12/24V 52 150C D EU DL rw A MODULE BOOST 30PSI 10-180 12/24 VLB MODULE TEMP OIL 300F/150C VDO 12/24 VLW VLW_OilTemp12/24V_52_150°C_D_EU_DL_wo_C MODULE OIL 400PSI/30BAR 10-180 12/24 VLW MODULE OIL 100PSI/7BAR 240-33 12/24 VLW MODULE OIL 150PSI/10BAR 10-180 12/24 VLW VLW PressOil 12/24V 52 10bar D EU DL tc VLW PressOil 12/24V 52 10bar D EU DL tb VLW PressOil 12/24V 52 10bar S EU DL tb VLW PressOil 12/24V 52 5bar D EU DL tc A VLW PressOil 12/24V 52 80psi D EU DL rb VLW PressTr 12/24V 52 25bar D EU DL tc A VLW PressTr 12/24V 52 25bar S EU DL tb A VLW PressTu 12/24V 52 2bar S EU DL tb A VLW PressOil 12/24V 52 10bar S EU DL tc VLW PressOil 12/24V 52 150psi D EU DL rw VLW PressOil 12/24V 52 30bar D EU DL rw VLW PressOil 12/24V 52 5bar S EU DL tc A VLW PressTr 12/24V 52 400psi D EU DL rw VLW PressTu 12/24V 52 2bar S EU DL tc A VLW_OilPress12/24V_52_5 bar_S_EU_DL_wo_ VLW_BrePress12/24V_52_10 bar_S_EU_DL_wo VLW_GeaPress12/24V_52_25 bar_S_EU_DL_wo VLW_OilPress12/24V_52_10 bar_S_EU_DL_wo MODULE OIL 80PSI 10-180 12/24 VLW MODULE BOOST 2BAR/30PSI 10-180 12/24 VLB VLW_OilPress12/24V_52_5 bar_D_EU_DL_wo_ VLW_GeaPress12/24V_52_25 bar_D_EU_DL_wo VLW_GeaPress12/24V_52_30 bar_D_EU_DL_wo MODULE BOOST 2BAR/30PSI 10-180 12/24 VLW VLW_OilPress12/24V_52_10 bar_D_EU_DL_wo VLW_OilPress12/24V_52_25 bar_D_EU_DL_wo MODULE OIL 80PSI/5BAR 10-180 12/24 VLW VLW PressBr 12V 52 16bar tb C Renault MODULE OIL 80PSI/5BAR 240-33 12/24 VLB MODULE OIL 150PSI/10BAR 240-33 12/24 VLB VLW TempWa 12/24V 52 120C D EU DL tc A VLW TempWa 12/24V 52 120C D EU DL tb A VLW TempWa 12/24V 52 120C S EU DL tb A VLW TempWa 12/24V 52 120C D EU DL tc A VLW TempWa 12/24V 52 120C S EU DL tc A VLW_WaTemp12/24V_52_120°C_S_EU_DL_wo_C VLW_HyTemp12/24V_52_120°C_S_EU_DL_wo_C VLW_WaTemp12/24V_52_120°C_S_EU_DL_wo_C</p>	<p>A2C60002589 A2C59501209 A2C59501210 A2C59513211 A2C59514161 A2C59514162 A2C59514163 A2C59514233 A2C59514234 A2C60000953 A2C60001077 A2C60001079 A2C59501209 A2C59501210</p>	<p>VL4W Temp 52 SL tc C MANITOU MODULE 16V-5bar-120C-1/1 VDO 12V 110ØVLB MODULE 16V-5bar-120C-1/1 VDO 12V 110ØVLW VLW_OelTemp12/24V_52_150°C_D_EU_DG_rs_C VLW TempOil 12/24V 52 150C D EU DL tc A VLW TempOil 12/24V 52 150C D EU DL tb A VLW TempOil 12/24V 52 150C S EU DL tb A VLW TempOil 12/24V 52 150C S EU DL tc A VLW TempOil 12/24V 52 300F D EU DL rw A VLW_OilTemp12/24V_52_150°C_S_EU_DL_wo_C VLW_OilTemp12/24V_52_150°C_D_EU_DL_wo_C MODULE TEMP OIL 300F/150C VDO 12/24 VLB MODULE 16V-5bar-120C-1/1 VDO 12V 110ØVLB MODULE 16V-5bar-120C-1/1 VDO 12V 110ØVLW</p>
--	---	--	---

B000046

Temperature gauge, pressure gauge, rudder angle gauge, trim gauge, fuel gauge, fresh water gauge for lever-type sensor

B000046

11/18

GB

2



## Safety information

- The product was developed, manufactured and inspected according to the basic safety requirements of EC Guidelines and state-of-the-art technology.
- The instrument is designed for use in grounded vehicles and machines as well as in pleasure boats, including non-classified commercial shipping.
- Use our product only as intended. Use of the product for reasons other than its intended use may lead to personal injury, property damage or environmental damage. Before installation, check the vehicle documentation for vehicle type and any possible special features!
- Use the assembly plan to learn the location of the fuel/hydraulic/compressed air and electrical lines!
- Note possible modifications to the vehicle, which must be considered during installation!
- To prevent personal injury, property damage or environmental damage, basic knowledge of motor vehicle/shipbuilding electronics and mechanics is required.
- Make sure that the engine cannot start unintentionally during installation!
- Modifications or manipulations to VDO products can affect safety. Consequently, you may not modify or manipulate the product!
- When removing/installing seats, covers, etc., ensure that lines are not damaged and plug-in connections are not loosened!
- Note all data from other installed instruments with volatile electronic memories.

### Safety during installation:

- During installation, ensure that the product's components do not affect or limit vehicle functions. Avoid damaging these components!
- Only install undamaged parts in a vehicle!
- During installation, ensure that the product does not impair the field of vision and that it cannot impact the driver's or passenger's head!
- A specialized technician should install the product. If you install the product yourself, wear appropriate work clothing. Do not wear loose clothing, as it may get caught in moving parts. Protect long hair with a hair net.
- When working on the on-board electronics, do not wear metallic or conductive jewelry such as necklaces, bracelets, rings, etc.
- If work on a running engine is required, exercise extreme caution. Wear only appropriate work clothing as you are at risk of personal injury, resulting from being crushed or burned.
- Before beginning, disconnect the negative terminal on the battery, otherwise you risk a short circuit. If the vehicle is supplied by auxiliary batteries, you must also disconnect the negative terminals on these batteries! Short circuits can cause fires, battery explosions and damages to other electronic systems. Please note that when you disconnect the battery, all volatile electronic memories lose their input values and must be reprogrammed.
- If working on gasoline boat motors, let the motor compartment fan run before beginning work.
- Pay attention to how lines and cable harnesses are laid so that you do not drill or saw through them!
- Do not install the product in the mechanical and electrical airbag area!
- Do not drill holes or ports in load-bearing or stabilizing stays or tie bars!
- When working underneath the vehicle, secure it according to the specifications from the vehicle manufacturer.

### No smoking! No open fire or lights!

- Note the necessary clearance behind the drill hole or port at the installation location. Required mounting depth: 65 mm.
- Drill small ports; enlarge and complete them, if necessary, using taper milling tools, saber saws, keyhole saws or files. Debur edges. Follow the safety instructions of the tool manufacturer.
- Use only insulated tools, if work is necessary on live parts.
- Use only the multimeter or diode test lamps provided, to measure voltages and currents in the vehicle/machine or boat. Use of conventional test lamps can cause damage to control units or other electronic systems.
- The electrical indicator outputs and cables connected to them must be protected from direct contact and damage. The cables in use must have sufficient insulation and electric strength and the contact points must be safe from touch.
- Use appropriate measures to also protect the electrically conductive parts on the connected consumer from direct contact. Laying metallic, uninsulated cables and contacts is prohibited.

### Safety after installation:

- Connect the ground cable tightly to the negative terminal of the battery.
- Reenter/reprogram the volatile electronic memory values.
- Check all functions.
- Use only clean water to clean the components. Note the Ingress Protection (IP) ratings (IEC 60529).



### Electrical connection:

- Note cable cross-sectional area!
- Reducing the cable cross-sectional area leads to higher current density, which can cause the cable cross-sectional area in question to heat up!
- When installing electrical cables, use the provided cable ducts and harnesses; however, do not run cables parallel to ignition cables or to cables that lead to large electricity consumers.
- Fasten cables with cable ties or adhesive tape. Do not run cables over moving parts. Do not attach cables to the steering column!
- Ensure that cables are not subject to tensile, compressive or shearing forces.
- If cables are run through drill holes, protect them using rubber sleeves or the like.
- Use only one cable stripper to strip the cable. Adjust the stripper so that stranded wires are not damaged or separated.
- Use only a soft soldering process or commercially available crimp connector to solder new cable connections!
- Make crimp connections with cable crimping pliers only. Follow the safety instructions of the tool manufacturer.
- Insulate exposed stranded wires to prevent short circuits.
- Caution: Risk of short circuit if junctions are faulty or cables are damaged.
- Short circuits in the vehicle network can cause fires, battery explosions and damages to other electronic systems. Consequently, all power supply cable connections must be provided with weldable connectors and be sufficiently insulated.
- Ensure ground connections are sound.
- Faulty connections can cause short circuits. Only connect cables according to the electrical wiring diagram.
- If operating the instrument on power supply units, note that the power supply unit must be stabilized and it must comply with the following standard: DIN EN 61000, Parts 6-1 to 6-4.

Temperature gauge, pressure gauge, rudder angle gauge, trim gauge, fuel gauge, fresh water gauge for lever-type sensor	B000046	11/18	3

## Procedures for installing VDO Viewline instruments

**1**  Before beginning, turn off the ignition and remove the ignition key. If necessary, remove the main circuit switch.


**2**   Disconnect the negative terminal on the battery. Make sure the battery cannot unintentionally restart.



- Before beginning, disconnect the negative terminal on the battery, otherwise you risk a short circuit. If the vehicle is supplied by auxiliary batteries, you must also disconnect the negative terminals on these batteries! Short circuits can cause fires, battery explosions and damages to other electronic systems. Please note that when you disconnect the battery, all volatile electronic memories lose their input values and must be reprogrammed.

**3**  If installing the instrument near a magnetic compass, note the magnetic safe distance to the compass.


**4**  The following rings may be installed as alternatives to the supplied front ring:

Front ring, flat; black	A2C5318604001
Front ring, flat; white	A2C5318602201
Front ring, flat; chrome	A2C5318602301
Front ring, triangular; black	A2C5318602401
Front ring, triangular; white	A2C5318602501
Front ring, triangular; chrome	A2C5318602601
Front ring, round; black	A2C5318602701
Front ring, round; white	A2C5318602801
Front ring, round; chrome	A2C5318602901

**5**  Place the new front ring on the instrument and press it on until it is flush with the instrument glass.

**6**   Conventional assembly. (Instrument is put into the drill hole from the front). The panel width may be within a range of 0.5 to 20 mm. The drill hole must have a diameter of 53 mm.

- Do not drill holes or ports in load-bearing or stabilizing stays or tie bars!
- Note the necessary clearance behind the drill hole or port at the installation location. Required mounting depth: 65 mm.
- Drill small ports; enlarge and complete them, if necessary, using taper milling tools, saber saws, keyhole saws or files. Deburr edges. Follow the safety instructions of the tool manufacturer.

**7**  For 52 mm instruments, the fastening nut can be mounted at position A or B. This allows you to realize various clamping heights.

Version A  
Clamping height 0.5 – 10 mm


Version B  
Clamping height 0.5 – 20 mm

A: 0.5... 10 mm  
B: 0.5... 20 mm

B000046


Temperature gauge, pressure gauge, rudder angle gauge, trim gauge, fuel gauge, fresh water gauge for lever-type sensor	B000046	11/18	4

8



If the instrument is mounted flush (i.e., from the back so that the instrument glass and the panel form one plane), the front ring must be removed. Press the instrument glass with both thumbs, while at the same time pressing the front ring forward from the instrument with both index fingers. Note the use of a tool in the adjacent figure.

9




- Do not drill holes or ports in load-bearing or stabilizing stays or tie bars!
- Note the necessary clearance behind the drill hole or port at the installation location. Required mounting depth: 65 mm.
- Drill small ports; enlarge and complete them, if necessary, using taper milling tools, saber saws, keyhole saws or files. Deburr edges. Follow the safety instructions of the tool manufacturer.

### Flush assembly


The recommended panel thickness is 1.5 to 3 mm. The drill hole must have a diameter of 48.1 mm. Ensure that the installation location is level and has no sharp edges.

10



Place the flush mount seal A2C53215640 on the instrument glass. Put the instrument into the drill hole from the back. Adjust the instrument so that the gauge is level and fasten it to the stud bolts on the rear side of the panel, using the flush mount fixing bracket A2C59510864.

11



Depending on the configuration, insert the cable into the 8-pin contact enclosure according to the following pin assignment. The contacts must audibly lock into place.

- |  |              |
|--|--------------|
| Pin 1 - Term. 15 - ignition plus 12/24 V | Red          |
| Pin 2 - Term. 31 - ground                | Black        |
| Pin 3 - SIGNAL GROUND                    | Blue/black   |
| Pin 4 - Term. 30 - steady power          | Brown        |
| Pin 5 - sensor signal                    | Green        |
| Pin 6 - Term. 58 - lighting              | Blue/red     |
| Pin 7 - warning LED ground               | Yellow/Black |
| Pin 8 - warning LED plus                 | Yellow/red   |

Now insert the plug into the gauge. Note the inverse polarity protection nose in the process.

Temperature gauge, pressure gauge, rudder angle gauge, trim gauge, fuel gauge, fresh water gauge for lever-type sensor


**B000046**

11/18



5

**12**



Connector set, 8-pin  
A2C59510850

Use the following connector to connect the instrument: Connector set, 8-pin - A2C59510850

The connector set is designed for a cable cross-section of 0.25 - 0.5 mm<sup>2</sup>. For other cross-sections, please use contacts made by Tyco.

Single contacts: Tyco No. 1355718-1 for 0.14 – 0.22 mm<sup>2</sup>  
Tyco No. 963729-1 for 0.5 – 0.75 mm<sup>2</sup>

Strip: Tyco No. 1355717-1 for 0.14 – 0.22 mm<sup>2</sup>  
Tyco No. 963715-1 for 0.5 – 0.75 mm<sup>2</sup>

Create a crimp connection using the contacts and the corresponding cables. Follow the instructions of the hand pliers manufacturer.

Use the following for this:

Hand pliers Tyco No. 539635-1  
and the tool Tyco No. 539682-2 for these hand pliers

Pay special attention to whether the crimp barrel clutches all individual wires in the cable, otherwise you risk a short circuit!



**Electrical connection:**

- Note cable cross-sectional area!
- Reducing the cable cross-sectional area leads to higher current density, which can cause the cable cross-sectional area in question to heat up!
- When installing electrical cables, use the provided cable ducts and harnesses; however, do not run cables parallel to ignition cables or to cables that lead to large electricity consumers.
- Fasten cables with cable ties or adhesive tape. Do not run cables over moving parts. Do not attach cables to the steering column!
- Ensure that cables are not subject to tensile, compressive or shearing forces.
- If cables are run through drill holes, protect them using rubber sleeves or the like.
- Use only one cable stripper to strip the cable. Adjust the stripper so that stranded wires are not damaged or separated.
- Use only a soft soldering process or commercially available crimp connector to solder new cable connections!
- Make crimp connections with cable crimping pliers only. Follow the safety instructions of the tool manufacturer.
- Insulate exposed stranded wires to prevent short circuits.
- Caution: Risk of short circuit if junctions are faulty or cables are damaged.
- Short circuits in the vehicle network can cause fires, battery explosions and damages to other electronic systems. Consequently, all power supply cable connections must be provided with weldable connectors and sufficiently insulated.
- Ensure ground connections are sound.
- Faulty connections can cause short circuits. Only connect cables according to the electrical wiring diagram.
- If operating the instrument on power supply units, note that the power supply unit must be stabilized and it must comply with the following standard: DIN EN 61000, Parts 6-1 to 6-4.



**13**

Designations in the wiring diagram:

- 30 - terminal 30 - steady power
- 15 - terminal 15 - connected (ignition) plus 12/24 V
- 58 - terminal 58 - lighting


You must comply with the wiring diagram.

- 31 - terminal 31 - ground
- F1 - fuse 5A quick-response
- C1 - 8-pin MQS connector




B000046

Temperature gauge, pressure gauge, rudder angle gauge, trim gauge, fuel gauge, fresh water gauge for lever-type sensor	B000046	11/18	6


**14** 

Align the instrument and hand-tighten the fastening nut. Ensure that the nut is not tightened with a torque greater than 400 Ncm.

\* Make sure the seal lays flat between the panel and the front ring.


**15** 

If you would like to omit the fastening nut, you may use the part set A2C59510854 as an alternative. This is recommended if the installation location is subject to vibratory loads. Screw the stud bolts into the provided drill holes in the enclosure. Max. stud bolt torque is 1.5 Nm.


**16** 

Place the bracket on the stud bolt and hand-tighten the knurled nut.


\* Make sure the seal lays flat between the panel and the front ring (see Fig. 14).

**17** 

Reconnect the battery after inspecting the connection.



- Please note that when you disconnect the battery, all volatile electronic memories lose their input values and must be reprogrammed.

**18** 

If necessary, replace the main circuit switch. Turn on the ignition and conduct a functional test. Reprogram any other instruments that may have lost their saved settings.

**19 Important:** Clean the instrument glass and front frame with water only. Do not use chemical agents.

<b>20 Accessories / Spare parts</b>	Bush contacts 0.25 – 0.5 mm <sup>2</sup>	A2C59510846	Flush mount seal	A2C5321564001
	Bush housing, 8-pin	A2C59510847	Fastening nut	A2C5300739801
	Bracket assembly mounting set	A2C59510854	Front ring, flat; black	A2C5318604001
	Flush mount fixing bracket	A2C59510864	Front ring, flat; white	A2C5318602201
	Adapter Cable	A2C59512947	Front ring, flat; chrome	A2C5318602301
	Make Point Switch	A2C59510886	Front ring, triangular; black	A2C5318602401
			Front ring, triangular; white	A2C5318602501
			Front ring, triangular; chrome	A2C5318602601
			Front ring, round; black	A2C5318602701
			Front ring, round; white	A2C5318602801
			Front ring, round; chrome	A2C5318602901
			Warning point control	A2C5951088601
			Protective connector cap, 8-pin	A2C5332466401
			Spinlock nut 52mm	A2C5205947101