

We recommend drilling a 3/16" (4.8mm) hole for the light wire before cutting the mounting hole.

Forward  
(Bow)

mounting screws  
7.00" (17.78 cm) Bolt  
Circle

Compass centerline  
should be parallel to  
the centerline of the  
boat.

Bezel Outline  
7 1/2" (19.05 cm)

Mounting hole  
Cut along this Line  
6 1/4" (15.88 cm)

**RITCHIE**<sup>®</sup>  
Mounting Template for  
the FB-500, SS-5000's & SF-500

Part # 5G-0108  
Rev E 6/10

