Infrared Motion Sensor

Battery 1 (+)

5A Fuse

12-24V Power (+)

5A Fuse

Ground (-)

Security 1

Wiring Cable 1

Ground (-)

Ground (-)

Note: Posi-Tap™ connectors, terminal block, or other connection type can be used to connect the wiring cable to sensor wires.

12-24v Power (+)

Installation Instructions:

1. Connect white sensor wire to Security 1 (pink) on the wiring cable.

2. Connect green sensor wire to common ground.

3. Connect black sensor wire to common ground.

4. Connect red sensor wire to 12-24V power source.

Product SKU: SM-ACC-INFR

12 V   N.C.   T AMP.   TRB

Infrared Motion Sensor

siren marine